Experimental Report

Experiment Course Title: Experiment	erimental of C	College Chemistry I
Experimental Project Name:		
A: Electrochemistry and Oxida	ation Reduction	<u>on</u>
B: Metal corrosion and corrosi	on protection	<u>l</u>
Name: 易弘睿 Yi Hongrui	Student No.: 20186103	
College: JCI	Specialty: N	Mechanical Engineering
Class: ME01	Mentor:	Chen Gang
Score:		
Teacher Comments:		_
		<u> </u>
		<u>.</u>

1. Purpose

Experiment A

- (1) Deepen the understanding of the electrode potential and the principle of electrolysis.
- (2) Understanding the application of electrolysis principle in electropolishing.
- (3) Familiar with the polishing process.

Experiment B

- (1) Understanding plating principles and methods.
- (2) Understand plating process.

2. Principle and Method

(1) Experiment A: Electropolishing:

The dissolution rate of the protruding part on the anode metal surface is larger than that of the concave part. After a period of electrolysis, the surface is smooth and shiny.

Take steel as an example: During the electropolishing, workpiece is anode as well as lead plate is cathode. Put them into electrolyte which is made up of chromic anhydride, phosphoric acid and sulphuric acid. Here are the chemical equations.

Anode equations:

$$Fe = Fe^{2+} + 2e^{-}$$

$$6Fe^{2+} + Cr2O72- + 14H+ = 6Fe3+ + 2Cr3+ + 7H2O$$

Cathode equations:

Fe³⁺ reacts with HPO₄²⁻ and SO₄²⁻, then generates Fe₂(HPO₄)₃ and Fe₂(SO₄)₃. As the electrolysis progresses, the concentration of the salts around the anode increases continuously, forming a kind of sticky flm on the metal surface, which increases the concentration of the electrolyte and reduces the conductivity. Due to uneven distribution of liquid film thickness and thick part of concave film, the current density is small, and Fe is not easy to dissolve and is passivated. The raised part of the film is thin, the current density is large, and the Fe is easy to dissolve and active. The convex part dissolves faster than concave part, and the roough surface becomes smooth.

$$2H^{+} + 2e^{-} = H_{2}(g)$$

 $Cr_{2}O_{7}^{2-} + 14H^{+} + 6e^{-} = 2Cr^{3+} + 7H_{2}O$

(2) Experiment B: Metal Plating:

The method of depositing a layer of metal on the surface of a metal or nonmetal workpiece by electrochemical process is called electroplating. The technology is widely used in various production and research departments of the national economy. The main function of electroplated coating is to improve the corrosion resistance of metal parts in the working environment. Decorate the appearance of the work piece, make it bright and beautiful. Improve work performance.

2. Materials and Instruments

Experiment A: Electropolishing:

(1) Instrument:

DC regulated power supply, three electrolytic cells, two thermometers.

(2) Materials:

HCl(1.9g.dm-3), H2SO4(1.84g.cm-3), H3PO4(1.7g.cm-3), glycerin, NaOH(s), Na2CO3(s), Na2CO3(s), CrO3(s).

Experiment B: Metal Plating:

Instrument:

DC regulated power supply, two copper pieces, two nickel pieces, beaker, electric furnace, sand paper, glass rod, wire.

(2) Materials:

Alkali wash: Na2CO3(25-30g.dm-3), NaOH(25-30g.dm-3)

Pickled: H2SO4(6mol.dm-3)

Plating: NiSO4(140g.dm-3), MgSO4(30g.dm-3), Na2SO4(50g.dm-3), H2BO3(20g.dm-3), NaCl(5g.dm-3)

4. Experimental Records and Calculation Experiment A:

(1) Unoil: Anode: 2 steel sheet Cathode: workpiece heater setting 120° Cathode 0.5A clean the workpiece

Expression: There are plenty of bubbles on the surface of workpiece. (Graph 1)



Graph 1



Graph 2

(2) Pickling: workpiece 40°C acid solution $5\text{min} > \text{wash by H}_2\text{O}$ 0.6A 3.1V

Expression: Sparse bubbles on the surface of the work piece. (Graph 2)

(3) Polishing: Anode: workpiece Cathode: 2 zinc plate Polishing solution 70°C Anode $0.6\text{A}\ 3.1\text{V}$ get the product

Expression: The surface of the workpiece is flashy and smooth.(Graph 3 & Graph 4)

Anode:
$$Fe = Fe^{2+} + 2e^{-}$$
 $6Fe^{2+} + Cr_2O_7^{2-} + 14H^+ = 6Fe^{3+} + 2Cr^{3+} + 7H_2O$
Cathode: $2H^+ + 2e^{-} = H_2(g)$ $Cr_2O_7^{2-} + 14H^+ + 6e^{-} = 2Cr^{3+} + 7H_2O$



Graph 3



Graph 4

(1) Grinding the copper workpiece with sand paper.

Expression: Get rid of rust stain and the surface is smooth.(Graph 5)



Graph 5

(2) Wash the workpiece degreasing solution wash acid solution wash 60°C stir 10min stir 1min

(3) Anode: 2 nickle sheet Cathode: workpiece plating solution 40°C turn off the power get the production wash

Expression: Sparse bubbles are on the surface. The surface of copper(workpiece) is plated by nickel. (Graph 6 & Graph 7)

Cathode:
$$Ni^{2+}+2e^- \rightarrow Ni$$
 $2H^++2e^- \rightarrow H_2 \uparrow$
Anode: $Ni-2e^- \rightarrow Ni^{2+}$



Graph 6



Graph 7

- 5. Results and Discussion
- (1) What is the principle of electropolishing?

It takes the metal products suspended in the electrolytic tank as the anode, electrolysis under specific conditions, through the dissolution of the anode metal, the surface of the products to eliminate fine uneven.

(2) What are the similarities and differences between electropolishing and electrochemical machining? Similarity: Both of them do the anodic dissolution to work.

Difference: Electropolishing is aimed to make the surface of workpiece smooth while electrochemical machining is used to shape the shape and size of.

- (3) What are the roles of the main components in polishing fluid for electropolishing?
 - $1.\ H_3PO_4$ and H_2SO_4 are added to adjust the PH value of the polishing fluid to ensure the chemical reaction during the polishing process
 - 2. CrO₃ is used as oxidizing agent
 - 3. Glycerin is added to the polishing fluid to improve its dispersion stability and reduce the agglomeration of abrasive particles.
- (4) Why should the workpiece be polished, alkali washed, and acid washed before electroplating?

Polishing: Remove stains and make surface relatively smooth.

Alkali washed: Remove grease on surface.

Acid washed: Remove rust on surface.

- (5) What are the factors related to the quality of the coating?
 - 1. Temperature 2. Current 3. PH in solution 4. Time for metal plating 5. current density
- (6) In order to ensure the quality of coating, what problems should be paid attention to in the process of experiment operation?
 - 1. Strictly control the process parameters (such as temperature, current density, PH value, plating time, etc.).
 - 2. Pretreatment must be done well. Preparation is important.